



This document contains Proprietary advance information which shall not be reproduced or transferred to others without the written permission of Polybus International. Polybus International is not responsible for any errors or omissions in this documentation.

Switches and Fuses number 1-16 starting from left side of board.